

Product Details

Guestroom Accessories

The Londoner



The Londoner Bill Presenter

Magnetic fold for the bill
Pen holder
Money compartment
Material: faux leather
(without pen)

Code	Version	W x H x D in mm
190029	taupe (brownish grey)	120 x 240 x 30
190082	black	120 x 240 x 30

Cleaning Instructions - Faux Leather:

- The faux leather type surface is non-porous and therefore requires little maintenance. It can be easily cleaned with a mild soap solution. Do NOT use harsh detergents or acidic based chemical solutions.
- Dampen a clean soft rag with soapy water; squeeze-off the excess water to avoid over-saturating the surface. Gently wipe the stains clean with the damp rag.
- Then wipe off the area with a clean dry soft rag. The trick is to dampen the leather with minimal moisture to allow efficient cleaning and to allow it to dry quickly to avoid damage.

ALISEO GmbH · Leutkirchstraße 63 · 77723 Gengenbach

Tel. +49 (0) 7803-60279-0

Fax +49 (0) 7803-60279-30

E-Mail: info@aliseo.de · Internet: www.aliseo.de

ALISEO GmbH
G E R M A N Y